

# MDC Digital Wallcovering JetTex Installation Instructions

## **STOP AND READ BEFORE INSTALLING**

Important – If at any time during the installation of this material a discrepancy is discovered, STOP. Contact your distributor or dealer to resolve before proceeding.

MDC Digital Wallcovering is manufactured and installed in sequentially numbered panels. Each shipment includes a panel-map which clearly shows the finished artwork and how the individual panels should be installed. All panels are marked with a number, with corresponding numbers indicated on the panel-map.

Before cutting, lay out panels in numeric order and examine goods to make certain no damage has occurred during shipping. Each panel should be inspected for color consistency, accuracy and proper mural dimension. Inspection and installation should be done under adequate/permanent lighting that represents the final lighting conditions as closely as possible.

It is recommended to trim the sides of each panel to the printed edge; being careful not to cut into the image and/or past the crop lines. This allows for an enhanced visual guide that will result in a more accurate pattern match.

Surface preparation, tools needed and installation techniques are similar to that of a professional installation of commercial wallcovering. The wall surface should be primed with a high quality, pigmented, acrylic wallcovering primer to a uniform light color with no marks. Apply a quality, pre-mixed, heavy-duty clay based strippable wallcovering adhesive to the primed wall surface. Once the adhesive has begun to tack up, start installation of digital wallcovering to the pasted surface.

**CAUTION** – do not crease panels.

Hang the first panel to a vertical line. Overlap subsequent panels to match crop lines and double cut on the wall. Care should be exercised so the wallboard underneath is not scored. The selvage (excess trimmed edge) should be removed from the wall and the seam closed within one hour. Seams should be straight, have a tight fit and be free from air and paste bubbles. Smoothing tool should be free of sharp edges and wrapped with a soft cloth to prevent scratching the panel surface. Carefully sponge

each panel with clean water to remove any excess adhesive. Change this wash water frequently. Blot these surfaces dry with a clean towel.

Re-inspect installation after each panel is hung. Any objectionable variations in color, pattern, panel match and/or panel size must be immediately communicated to the manufacturer's representative for resolution. Continuing to hang questionable material constitutes acceptance of product.