

Woodland Natural Wood

Care and Maintenance

Woodland Wood Wallcovering is designed to function long-term in a climate-controlled environment, with temperature levels between 60°F-80°F and relative humidity between 25%-55%. Abrupt changes or extreme levels of temperature or humidity can damage the product's adhesion to the wall.

Woodland is not designed for areas including, but not limited to, those with exposure to indoor pools, saunas, spas or outdoor environments.

Cleaning the wallcovering:

When it comes to cleaning Woodland, the following recommendations should be followed: Dusting: Light dust may be removed with a dry microfiber or cotton cloth.

Dusting: Light dust may be removed with a dry microfiber or cotton cloth. .

Light cleaning: To remove light residue or debris, lightly dampen a microfiber or cotton cloth, wiping the veneer following the direction of the wood grain. Use a dry microfiber or cotton cloth to wipe dry immediately. Use caution - excessive water will damage the wood.

Heavy cleaning: Apply diluted Murphy's Oil Soap to a wet microfiber or cotton cloth. Use in small sections at a time, and follow the manufacturer's provided instructions. Wipe clean to remove soap. Use caution - excessive water will damage the wood.

Heavy cleaning and Disinfecting: Apply Formula 409. Follow the manufacturer's provided instructions, using a dry microfiber or cotton cloth.

Disinfecting: Apply Lysol Disinfectant Spray. Follow manufacturer's provided instructions.

No penetrating chemicals, harsh abrasives, or oils should be used to care for Woodland. Products such as treated dust cloths, hardwood cleaners, liquid or wax products, or other cleaners that contain citrus oils, lemon oil, tung oil, or silicone are not recommended. Additionally, 2-in-1 cleaners with polish that may contain acrylics or urethane polish should not be used.

For additional information or technical support contact MDC Customer Care at 847-437-4000