

## CARE & MAINTENANCE

Standard Dry Erase Wallcovering | Magnet Receptive Dry Erase  
Wallcovering | Dry Erase Coating

### Before Writing on Dry Erase Surface

Before initial use of the writing surface, the material must be cleaned with Expo Cleaner and a soft cloth, then towel dried. Follow with clean water and a soft cloth. Towel dry. This will remove manufacturing residue and static electricity, optimizing the erasing qualities of the Dry Erase Surface.

### Markers

We recommend the use of Expo markers. Other dry erase markers can also be used, but should be tested for acceptability before use across the entire writing surface.

### Daily Cleaning

Most standard whiteboard erasers can be used for removing the dry erase markings, however some work better than others. Change erasers often, as they become soiled and will leave excessive marker residue on the surface. For cleaning marker residue build-up, use Expo brand dry erase cleaning solution and a soft towel.

### Projection / Low Glare Surfaces

A projection / low-glare dry erase surface requires more frequent cleaning than Standard (high-gloss) material. We sell a melamine foam eraser that works well when erasing these types of surfaces. While no dry erase markings will be permanent on the low-glare surface, it may be necessary to use our foam eraser and / or Expo Cleaner to bring these products back to “like new” condition.

### Long Term Care

We strongly suggest that entire surface be cleaned on a regular basis to insure the ultimate performance and appearance of the product over the long term.

### Warning

Do not use abrasive cleaners/cleaning tools, hard-edged erasers or sharp pointed writing instruments on the dry erase surface.