



# Zintra Baffles Wave **Installation Instructions**



PERSPECTIVE - 54.0" x 48.03" x 0.5"



PERSPECTIVE - 108.07" x 48.03" x 0.5"

# Zintra Baffles Wave Installation Instructions

## PARTS AND HARDWARE

(4 - 48" LONG, 6 - 108" LONG) CABLE WITH SWAGE END, AND BARREL



(4 - 48" LONG, 6 - 108" LONG) 1/4" - 20 HANGER BOLT (FOR USE WITH WOOD SUBSTRATE ONLY)




(4 - 48" LONG, 6 - 108" LONG) ADJUSTABLE FASTENER




(4 - 48" LONG, 6 - 108" LONG) END CAP



(2- 48" LONG, 3 - 108" LONG) CROSSRUNNER WITHOUT NOTCHES




(8 - 54" LONG, 16 - 108" LONG) ZINTRA BLADES (48" TYPICAL SHOWN)




(4 - 54" LONG, 8 - 108" LONG) WAVE CONNECTOR - IF CONNECTING MORE THAN 1 BAFFLE ASSEMBLY



(19 - 54" LONG, 39 - 108" LONG) BINDING BARREL




(2 - 54" LONG, 2 - 108" LONG) TUBE CONNECTOR - IF CONNECTING MORE THAN 1 BAFFLE ASSEMBLY




### YOU WILL NEED


SPIRIT LEVEL



DRILL



TAPE MEASURE



# Zintra Baffles Wave Installation Instructions


## STEP 1

CHECK TO SEE IF PACKAGE CONTAINS  
ALL COMPONENTS.

54" - 8 BLADES  
108" - 16 BLADES


54.0" x 48.03" x 0.5"

(A)



108.07" x 48.03" x 0.5"


(B)



## STEP 2

BEGIN WITH THE FIRST BAFFLE.

IMPORTANT: MAKE SURE THE  
CUTS ARE FACING INSIDE AND  
TOWARDS EACH OTHER.




# Zintra Baffles Wave Installation Instructions

## STEP 3



CONTINUE TO ADD THE REMAINING BAFFLES REQUIRED UNTIL ALL OF THE ASSEMBLY HAS BEEN ADDED (4 FOR 54" 8 FOR 108").

AFTER, CONNECT EACH WAVE BAFFLE TOGETHER (2 PROFILES) WITH THE BINDING BARREL.

ONCE THE BAFFLES ARE ON THE CROSSRUNNER, MAKE A DIAMOND SHAPE ON THE SIDE PROFILE BY SPREADING THE BAFFLE INTO A WAVE SHAPE.



SIDE PROFILE





## STEP 4

CONTINUE STEPS 2-3 TO MAKE THE WAVE BAFFLE ASSEMBLY (4 TOTAL FOR 54" LONG, 8 TOTAL FOR 108" LONG)

ONCE THE BAFFLES HAVE SPREAD, CONNECT THEM TOGETHER VIA ANOTHER SET OF BINDING BARREL ON THE MIDDLE OF THE BAFFLE.

NOTE: ZINTRA HOLE NEEDS TO BE POPPED OUT AND THE END BAFFLES NEED TO BE FLUSH WITH THE EDGE OF THE SHS TUBE.





# Zintra Baffles Wave Installation Instructions

## STEP 5


FIND THE LOCATIONS OF THE A.S.K'S IT WILL BE THE MIDPOINT BETWEEN THE FIRST BAFFLE AND SECOND BAFFLE ASSEMBLED (MARKED X ON DETAIL) FOR BOTH THE BACK AND FRONT.

THERE WILL BE 2 LOCATIONS PER CROSSRUNNER (TOTAL OF 4 ON (A) AND TOTAL OF 6 ON (B)).



## STEP 6

AFTER IDENTIFYING EACH CORRESPONDING POINT ON THE CEILING SUBSTRATE, TO THE POINTS MARKED ON STEP 7, DRILL AND ATTACH 1/4"-20 DOUBLE SIDED HANGER BOLT TO SUBSTRATE. REFERENCE DETAIL (SUPPLIED FOR WOOD ANCHORING ONLY). FOR ALL OTHER SUBSTRATES, STUDS/ ANCHORS MUST BE SOURCED BY THE INSTALLER.




## STEP 7

A. IDENTIFY THE THREADED END OF THE BARREL AND THE SWAGE END OF THE WIRE.

B. INSERT THE PLAIN END OF THE SUPPLIED WIRE THROUGH THE LARGE THREADED END OF THE BARREL UNTIL THE SWAGE END IS SEATED IN THE BARREL.

C. ATTACH THE THREADED END OF THE BARREL TO 1 / 4"-20




# Zintra Baffles Wave Installation Instructions

## STEP 8

A. INSERT THE PLAIN END OF THE SUPPLIED WIRE THROUGH ONE SIDE OF THE ADJUSTABLE FASTENERS.

B. LOOP THE WIRE AROUND THE CROSSRUNNER WHERE MARKED.


C. RE-INSERT THE PLAIN END OF THE WIRE INTO THE REMAINING SIDE OF THE ADJUSTABLE FASTENER UNTIL SECURE.



## STEP 9


ONCE THE BAFFLE IS PROPERLY SUSPENDED, TRIM THE EXCESS WIRE (IF NECESSARY) WITH WIRE CUTTERS.

**NOTE: WIRE IS INFINITELY ADJUSTABLE BY DEPRESSING TAB ON APPROPRIATE SIDE.**




## STEP 10

A. CAP THE END OF THE SUSPENSION RODS BY PRESSING THE SUPPLIED PVC CAPS UNTIL SECURE.



B. TO CONNECT MULTIPLE BAFFLE SYSTEMS TOGETHER USE THE SUPPLIED ZINTRA CONNECTORS. INSERT ONE OF THEM HALF WAY INTO THE CROSSRUNNER, AND THE OTHER HALF INTO THE ADJACENT CROSSRUNNER. ADJUST AS NEEDED FOR ALIGNMENT.




# Zintra Baffles Wave Installation Instructions

C. CONNECT THE WAVE ASSEMBLIES  
USING THE WAVE CONNECTORS.


THIS WILL BE INSERTED INSIDE THE SIDE  
AS SHOWN IN SEQUENCE 1-3

NOTE: EACH WAVE BAFFLE ASSEMBLY  
WILL NEED 1 WAVE CONNECTOR BETWEEN  
EACH OTHER.




WAVE CONNECTOR


DETAIL Z




1



2



TOP PROFILE  
WAVE CONNECTOR SHOW IN RED



3