



# ZINTRA Sliding Screen INSTALLATION INSTRUCTIONS



\*Pattern shown as an example only.  
Instructions apply to all Pattern designs.

# ZINTRA Sliding Screen INSTALLATION INSTRUCTIONS

MEASURE THE ALUMINUM DOUBLE-TRACK TO ASSURE CORRECT LENGTH, CUT AS NEEDED.




## STEP 2


ATTACH THE DOUBLE-TRACK TO A CEILING (OPTION 1) OR WALL (OPTION 2)

### OPTION 1

A. DRILL HOLES THROUGH THE TOP OF THE TRACK AT THE APPROPRIATE LOCATIONS FOR THE INSTALLATION SITE. MAKE SURE THE HOLES ARE COUNTERSUNK SO THE HEAD OF THE SCREWS DO NOT INTERFERE WITH THE ROLLERS.




B. USING THE PROPER SCREWS AND HARDWARE FOR THE SUBSTRATE (NOT INCLUDED), AFFIX THE TRACK TO THE CEILING.




### OPTION 2


A. DRILL HOLES THROUGH THE FRONT TRACK. THESE HOLES SHOULD BE LARGE ENOUGH FOR THE SCREW HEADS TO PASS COMPLETELY THROUGH.



B. DRILL HOLES THROUGH THE BACK TRACK. MAKE SURE THESE HOLES ARE CENTERED ON THE HOLES DRILLED IN STEP (A), ALSO MAKE SURE THESE HOLES ARE COUNTERSUNK SO THE HEAD OF THE SCREW DOES NOT INTERFERE WITH THE ROLLERS ONCE ASSEMBLED.




C. USING THE PROPER SCREWS AND HARDWARE FOR THE SUBSTRATE (NOT INCLUDED), SCREW THE TRACK TO THE WALL.




## STEP 3

HANG THE PANELS WITH THE PRE-INSTALLED ROLLERS ON THE TRACKS.




## STEP 4

ADHERE THE PANEL STOPPERS TO THE TRACK BY PUTTING A SMALL 1" BEAD OF SILICONE ADHESIVE AT THE DESIRED LOCATION AND PLACING THE STOPPER IN PLACE. NOTE THIS MAY NOT BE DIRECTLY AT THE END OF THE TRACK, DEPENDING ON THE DESIGN OF THE PANELS AND LOCATION OF THE ROLLERS. ALLOW 24 HOURS FOR THE ADHESIVE TO CURE.



## STEP 5


PLACE THE ZINTRA ENDCAPS TO THE ENDS OF THE TRACK AS NEEDED.




NOTE: MULTIPLE TRACKS MAY BE BUTT JOINED TO CREATE LONGER TRACKS. SECURE EACH TRACK PER THE INSTRUCTIONS ABOVE, MAKING SURE THE TRACKS ARE TIGHTLY BUTT JOINED AND ALIGNED.

# ZINTRA Sliding Screen INSTALLATION INSTRUCTIONS


## SLIDING SCREEN PARTS



ZINTRA PANEL WITH  
HARDWARE ATTACHED



ENDCAP



ALUMINUM SLIDING  
TRACK



PANEL STOPPERS

NOTE: QUANTITY MAY VARY DEPENDING ON THE SIZE OF THE INSTALLATION  
YOU WILL NEED SILICONE ADHESIVE - LOCTITE POWERGRAB  
RECOMMENDED (NOT INCLUDED)