



# Zintra Sticks Curved Suspension Kit **Installation Instructions**



NARROW



WIDE


# Zintra Sticks Curved Suspension Kit

## Installation Instructions


### PARTS AND HARDWARE

*FOR A TYPICAL ASSEMBLY*


CABLE WITH SWAGE END AND BARREL - (6)



ADJUSTABLE FASTENER - (6)




HANGER BOLT - (6)




### TOOLS NEEDED

*FOR A TYPICAL ASSEMBLY*


SPIRIT LEVEL



TAPE MEASURE



CORDLESS SCREWDRIVER (PHILLIPS BIT)




## SUSPENSION METHOD

### STEP 1

1.1 DETERMINE THE SUSPENSION POINTS FOR THE ZINTRA STICKS CURVED SYSTEM THAT BEST SUIT THE SITE SPECIFIC INSTALATION. IT IS RECOMENDED TO HAVE TWO POINTS FOR EACH CROSSRUNNER.


1.2 ONCE THE SUSPENSION POINTS ON THE ZINTRA STICKS CURVED HAVE BEEN SELECTED, INDENTIFY THE CORRESPONDING POINTS ON THE CEILING SUBSTRATE.




# Zintra Sticks Curved Suspension Kit Installation Instructions

## STEP 2

2.1 INSTALL THE 1/4"-20 HANGER BOLTS TO THE SUBSTRATE. THE SUPPLIED HANGER BOLTS ARE INTENDED FOR USE IN WOOD ONLY. FOR OTHER SUBSTRATES THE INSTALLER WILL NEED TO SOURCE THE APPROPRIATE HARDWARE.




2.2 IDENTIFY THE THREADED END OF THE BARREL AND THE SWAGE END OF THE CABLE. INSERT THE PLAIN END OF THE SUPPLIED WIRE THROUGH THE LARGE THREADED END OF THE BARREL UNTIL IT IS FULLY SEATED IN THE BARREL. ATTACH THE THREADED END OF THE BARREL TO THE 1/4"-20 HANGER BOLT.



# Zintra Sticks Curved Suspension Kit Installation Instructions

## STEP 3


3.1 INSERT THE PLAIN END OF THE CABLE THROUGH ONE SIDE OF THE ADJUSTABLE FASTENER. LOOP THE WIRE AROUND THE CROSSRUNNER AT THE PREDETERMINED LOCATIONS. RE-INSERT THE PLAIN END OF THE CABLE THROUGH THE REMAINING SIDE OF THE ADJUSTABLE FASTENER.



## STEP 4

4.1 ONCE THE ZINTRA STICKS CURVED SYSTEM IS PROPERLY SUSPENDED, TRIM THE EXCESS CABLE. THE CABLE IS ADJUSTABLE BY DEPRESSING TAB ON APPROPRIATE SIDE.

**NOTE: WIRE IS INFINITELY ADJUSTABLE BY DEPRESSING TAB ON APPROPRIATE SIDE.**




# Zintra Sticks Double Sided Landscape **Installation Instructions**

## STEP 5

### FINISHING INSTALL

A. CAP THE END OF THE CROSSRUNNER BY PRESSING THE SUPPLIED PVC CAPS UNTIL SECURE.

B. TO CONNECT MULTIPLE ZINTRA STICKS CURVED SYSTEMS TOGETHER USE THE SUPPLIED ZINTRA CONNECTORS. INSERT ONE OF THEM HALF WAY IN THE CROSSRUNNER, AND THE OTHER HALF INTO THE ADJACENT CROSSRUNNER. ADJUST AS NEEDED FOR ALIGNMENT.



If you are unsure about the installation of the system which has been specified for your project, please stop and verify the details with both the specifier and the MDC Zintra team. Remember that while MDC may be able to assist you with common methods of attachment, others may be unique to your project and need to be discussed directly with your specifier.