



Zintra Sticks Double Sided Portrait **Installation Instructions**



FULL WALL
NARROW



FULL WALL
WIDE

Zintra Sticks Double Sided Portrait Installation Instructions


PARTS AND HARDWARE

FOR A TYPICAL ASSEMBLY


ZINTRA STICKS - (16) WIDE OR (36) NARROW




(2) ZINTRA END STI




(2) VERTICAL ALUMINIUM T




(6) HORIZONTAL ALUMINIUM T




(4) ACRYLIC C



(4) LEVELING FEET




(12) COUNTERSUNK B




TOOLS NEEDED

FOR A TYPICAL ASSEMBLY - FULL SET / HALF BUNDLE


SPIRIT LEVEL




TAPE MEASURE



DROP SAW WITH SUITABLE BLADE FOR ALUMINIUM CUTTING



SET OF ALLEN KEYS




Zintra Sticks Double Sided Portrait **Installation Instructions**

STEP 1



MEASURE THE HEIGHT [X] OF THE INSTALL.
FOR SAFE AND SECURE INSTALL X CAN NOT EXCEED 2921mm [115"]

IF NEEDED CUT THE VERTICAL ALUMINIUM TUBE TO SUIT

OPTIMAL Y DISTANCE IS $Y = X - 76\text{mm}$ [3"]




THE MAXIMUM CUT FROM EACH ALUMINIUM TUBE END IS 30mm [1.2"]



Zintra Sticks Double Sided Portrait **Installation Instructions**

STEP 2


LEVELING FEET SET INSTALL



Zintra Sticks Double Sided Portrait Installation Instructions

STEP 3

FRAME ASSEMBLY x2




Zintra Sticks Double Sided Portrait **Installation Instructions**

STEP 4

STICKS INSTALL

ZINTRA STICKS - (8) WIDE OR (18) NARROW




Zintra Sticks Double Sided Portrait **Installation Instructions**

STEP 5



END STICKS INTALL

ZINTRA END STICKS - (2) WIDE OR (2) NARROW



5.1 ROTATE PREVIOUS INTALL UPSIDE DOWN




5.2 INSTALL END STICKS - KEEP END STICKS OPEN FOR FURHER INSTALL



Zintra Sticks Double Sided Portrait **Installation Instructions**

STEP 6

ACRYLIC COMB INSTALL x4



Zintra Sticks Double Sided Portrait **Installation Instructions**

STEP 7



STICKS INTALL

ZINTRA STICKS - (8) WIDE OR (18) NARROW



7.1 LOCK END STICKS

7.2 FOLD STICKS AND INSTALL




Zintra Sticks Double Sided Portrait **Installation Instructions**


STEP 8

FINAL INSTALL

8.1 ROTATE ASSEMBLY TO VERTICAL POSITION



8.2 USING SPIRIT LEVEL AND ADJUSTING LEVEL FEET FINISH THE INSTALL



If you are unsure about the installation of the system which has been specified for your project, please stop and verify the details with both the specifier and the MDC Zintra team. Remember that while MDC may be able to assist you with common methods of attachment, others may be unique to your project and need to be discussed directly with your specifier.