


# Zintra Sticks Quadratic **Installation Instructions**



# Zintra Sticks Quadratic Installation Instructions


## PARTS AND HARDWARE

ZINTRA STICKS


NARROW - 1" - (6)




NARROW - 2" - (4)




NARROW - 3" - (4)



NARROW - 4" - (2)




STANDARD ALUMINIUM TUBE WITH NOTCHES - (7)




## TOOLS NEEDED

*FOR A TYPICAL ASSEMBLY - FULL SET / HALF BUNDLE*


SPIRIT LEVEL




TAPE MEASURE



DRILL




DROP SAW WITH SUITABLE BLADE FOR ALUMINIUM CUTTING



SUITABLE SCREWS FOR DIFFERENT SURFACES - (14)

*SCREWS ARE NOT INCLUDED - INSTALLER TO SUPPLY BASED ON FIXING SUBSTRATE*



# Zintra Sticks Quadratic Installation Instructions

## STEP 1


MEASURE THE HEIGHT [X] OF THE INSTALL AND CUT THE ALUMINIUM TO SUIT

NOTE: AFTER MEASURING AND MARKING WHERE TO CUT THE ALUMINIUM TUBE, COUNT THE NUMBER OF NOTCHES TO ENSURE IT WILL SUIT THE QUANTITY OF STICKS REQUIRED. FOR EXAMPLE, A WIDE STICK USES 4 NOTCHES, THEREFORE THE NOTCHES IN THE ALUMINIUM TUBE WILL NEED TO EQUAL A MULTIPLE OF 4.

USE A LASER LEVEL OR SPIRIT LEVEL TO MARK ALUMINIUM POSITION ON THE WALL.

MAX DISTANCE FROM TUBE CENTRES IS 450mm [17.71"]

MAX DISTANCE BETWEEN END OF STICK AND FIRST TUBE CENTRE IS 150mm [5.9"]



## STEP 2


DRILL HOLES IN ALUMINIUM TUBES IN LOCATIONS TO SUIT SUPPORT IN WALL (STUD LOCATION ETC)

SCREW ALUMINIUM TUBES TO WALL

DRYWALL SURFACE: USE DRYWALL ANCHOR AND SUITABLE SCREW

TIMBER SURFACE: USE SELF TAPPING TIMBER SCREW

MASONARY SURFACE: USE MASONARY ANCHOR AND SUITABLE SCREW





# Zintra Sticks Quadratic

## Installation Instructions

### STEP 3

FOLD ZINTRA STICKS - 2", 3", 4"

NOTE: ZINTRA STICK 1" - COMES FOLDED AND GLUED.




QUADRATIC NARROW

# Zintra Sticks Quadratic Installation Instructions




## STEP 4

INSERT ZINTRA STICKS INTO TUBE NOTCHES AS SHOWN



FOR BEST RESULTS USE CORRECT QUADRATIC STICKS  
INSTALL SEQUENCE.

AS SHOWN



# Zintra Sticks Quadratic **Installation Instructions**

## FINISHED INSTALL

NOTE: CAN ADD STICKS TRIM TO EDGES (SIDES OR BOTTOM) FOR ALTERNATE FINISH

