



Zintra Sticks and Trim **Installation Instructions**



Zintra Sticks and Trim **Installation Instructions**


YOU WILL NEED

SUITABLE SCREWS


SCREWS ARE NOT INCLUDED - INSTALLER TO SUPPLY BASED ON FIXING SUBSTRATE



DROP SAW WITH SUITABLE BLADE FOR ALUMINUM CUTTING




DRILL




HIGH STRENGTH CONSTRUCTION ADHESIVE




CAULK GUN



TAPE MEASURE



LEVEL





Zintra Sticks and Trim Installation Instructions

STEP 1

MEASURE THE SPACE OF THE DOOR OR WINDOW WHERE THE STICKS WILL BE INSTALLED.

THIS IS GOING TO DETERMINE THE DIMENSIONS AT WHICH THE STICKS WILL BE CUT TO.

FRONT VIEW



STEP 2


MEASURE THE WIDTH [X] OF THE INSTALL AND CUT THE ALUMINUM TO SUIT

NOTE: AFTER MEASURING AND MARKING WHERE TO CUT THE ALUMINUM TUBE, COUNT THE NUMBER OF NOTCHES TO ENSURE IT WILL SUIT THE QUANTITY OF STICKS REQUIRED. FOR EXAMPLE, A WIDE STICK USES 4 NOTCHES, THEREFORE THE NOTCHES IN THE ALUMINUM TUBE WILL NEED TO EQUAL A MULTIPLE OF 4.

USE A LASER LEVEL OR SPIRIT LEVEL TO MARK ALUMINIUM POSITION ON THE WALL. MAX DISTANCE FROM TUBE CENTERS IS 17.71". MAX DISTANCE BETWEEN END OF STICK AND FIRST TUBE CENTER IS 5.9"

INSTALL STANDARD ALUMINUM TUBE INTO THE WALL. THESE WILL REQUIRE (2) SCREWS PER (1) ALUMINIUM TUBE

NOTE: AN ADDITIONAL ALUMINIUM TUBE NEEDS TO BE INSTALLED ABOVE THE WINDOW/ DOOR EDGE. MAX DISTANCE FROM THE EDGE TO NEXT TUBE CENTER IS 5.9"



Zintra Sticks and Trim Installation Instructions

STEP 3


DRILL HOLES IN ALUMINIUM TUBES IN LOCATIONS TO SUIT SUPPORT IN WALL (STUD LOCATION ETC)

SCREW ALUMINUM TUBES TO WALL
DRYWALL SURFACE: USE DRYWALL

ANCHOR AND SUITABLE SCREW



TIMBER SURFACE: USE SELF TAPPING TIMBER SCREW

MASONARY SURFACE: USE MASONARY ANCHOR AND SUITABLE SCREW




STEP 4

INSERT ZINTRA STICKS INTO TUBE NOTCHES AS SHOWN



STICK




STICK - TRIM

Zintra Sticks and Trim


Installation Instructions

STEP 5

CUT STICK TO FIT FROM CEILING TO EDGE OF WINDOW/DOOR
(DIMENSION A) SHOWN BELOW




CUT TRIMS TO FIT FROM CEILING TO EDGE OF
WINDOW/DOOR (DIMENSION B) SHOWN BELOW



Zintra Sticks and Trim Installation Instructions


STEP 6

USE THE DROP SAW TO CUT ZINTRA STICKS AND STICKS TRIM TO MEASURED DIMENSIONS



ZINTRA
STICK




CUT STICKS TRIM AT 45 DEGREE ANGLES



STICKS TRIM VARIATIONS

STEP 7


INSERT ZINTRA STICKS INTO TUBE NOTCHES AS SHOWN



Zintra Sticks and Trim Installation Instructions



STEP 8

DRY FIT STICKS TRIM TO ENSURE A GOOD FIT



STEP 9

APPLY CONSTRUCTION ADHESIVE TO INSIDE OF STICKS TRIM. THEN STICK TO ZINTRASTICKS THAT ARE ALREADY INSTALLED



Zintra Sticks and Trim **Installation Instructions**

