



ZINTRA

STANDARD INDIVIDUAL BOX BAFFLE
2362MM LENGTH (93") + 1000MM (39.4")
INSTALLATION INSTRUCTIONS



PARTS AND HARDWARE

93" - (3) CABLE WITH SWAGE END, AND BARREL; 39.4" - (2) CABLE WITH SWAGE END, AND BARREL




93" - (3) 1/4" - 20 HANGER BOLT; 39.4" - (2) 1/4" - 20 HANGER BOLT (FOR USE WITH WOOD SUBSTRATE ONLY)



93" - (3) ADJUSTABLE FASTENER; 39.4" - (2) ADJUSTABLE FASTENER



(1) BOX BAFFLE



ZINTRA

STANDARD INDIVIDUAL BOX BAFFLE


2362MM LENGTH (93") + 1000MM (39.4")

INSTALLATION INSTRUCTIONS

BAFFLE ASSEMBLY

STEP 1

DRILL AND ATTACH 1/4" - 20 DOUBLE SIDED HANGER BOLT TO SUBSTRATE. REFERENCE DETAIL (SUPPLIED FOR WOOD ANCHORING ONLY). FOR ALL OTHER SUBSTRATES, STUDS/ANCHORS MUST BE SOURCED BY THE INSTALLER.




STEP 2

A. IDENTIFY THE THREADED END OF THE BARREL AND THE SWAGE END OF THE WIRE.

B. INSERT THE PLAIN END OF THE SUPPLIED WIRE THROUGH THE LARGE THREADED END OF THE BARREL UNTIL THE SWAGE END IS SEATED IN THE BARREL.

C. ATTACH THE THREADED END OF THE BARREL TO 1/4" - 20 HANGER BOLT.



ZINTRA

STANDARD INDIVIDUAL BOX BAFFLE

2362MM LENGTH (93") + 1000MM (39.4")



INSTALLATION INSTRUCTIONS

STEP 3

A. INSERT THE PLAIN END OF THE SUPPLIED WIRE THROUGH ONE SIDE OF THE ADJUSTABLE FASTENERS.

B. INSERT THE WIRE THROUGH (b1) AND OUT (b2)

C. RE-INSERT THE PLAIN END OF THE WIRE INTO THE REMAINING SIDE OF THE ADJUSTABLE FASTENER UNTIL SECURE.



STEP 4

ONCE THE BAFFLE IS PROPERLY SUSPENDED, TRIM THE EXCESS WIRE (IF NECESSARY) WITH WIRE CUTTERS.

NOTE: WIRE IS INFINITELY ADJUSTABLE BY DEPRESSING TAB ON APPROPRIATE SIDE.

